



# Trust your water again.

<http://www.thevattencompany.com/> 1.800.945.5782

## Instructions for Whole House (WH) System Installation

The WH installation requires cutting into the main water lines and may require *a plumber*.

1. Isolate the unit with ball valves so it can be removed or accessed for maintenance and changing filters. Transition cold water supply line to 3/4". Both sides should be 3/4" male threads to screw into the unit. Use teflon tape on the threads.
2. The red buttons are for pressure relief prior to changing filters.
3. When attaching the housings to the top assembly, pay close attention to the black "O" rings that sit inside the housing rim. Be sure they are in place and not crimped when the housings are tightened. At the factory, we spray the threads lightly with silicone lubricant.
4. Attach a ply backing board to the wall. The WH unit will be mounted directly onto ply backing for secure attachment to the wall.
5. Build a small shelf a few inches below the housing bottom. This will make it easier to handle the heavy housing when replacing filters.

